



# Atomic Force Microscopy


**Kathy Walsh**

Senior Research Scientist

**Scanning Probe Microscopy**

Materials Research Laboratory  
Central Research Facilities


Physics 403  
11/1/22



# Illinois Materials Research Lab


## Central Research Facilities

- User facility—anyone can be trained
  - UIUC and non-UIUC researchers welcome
  - Undergraduate researchers welcome
  - Staff collaboration or analysis available
- [mrl.illinois.edu/facilities](http://mrl.illinois.edu/facilities)
- [mrl-facilities@illinois.edu](mailto:mrl-facilities@illinois.edu)




# Looking at Surfaces

## Optical Microscopy




## Scanning Electron Microscopy



Adapted from  
[https://myscope.training/#/SEMlevel\\_2\\_13](https://myscope.training/#/SEMlevel_2_13)  
(CC BY-SA 4.0)


# Surface XYZ Coordinates Needed

**3D Optical Profilometry**



blue glitter crayon tip




**Atomic Force Microscopy**



pencil "lead"



# Topics for Today

- How AFM works
- Featured applications
  - Topography
    - Profiles, step height
    - Roughness
  - Phase
  - Conductive AFM
- Issues and artifacts
- Image processing



# What's an Atomic Force Microscope?



“Atomic Force” Microscopy—**forces** between atoms in the tip and **atoms** in the sample



false-color surface topographs




# What's an Atomic Force Microscope?

- “Atomic Force”—interactions between tip and sample
  - Not actual atomic resolution (usually)
  - Nanoscale lateral resolution (depends on tip)
  - Sub-angstrom vertical resolution
- “Microscope”—surface topograph (false color)



# What's an Atomic Force Microscope?

- “Atomic Force”—interactions between tip and sample
  - Sub-angstrom vertical resolution
  - Not actual atomic resolution (usually)
  - Nanoscale lateral resolution (depends on tip)
- “Microscope”—surface topograph (false color)
- Tip at the end of a cantilever
- Raster tip over surface to build up an image
- Also sensitive to sample stiffness, adhesion, other properties depending on tip choices





Turquoise, 1 $\mu\text{m}$  x 1 $\mu\text{m}$   
color overlay: phase

# Typical AFM Scales



(only what's pretty common, not all of what's possible)

- Image sizes -- few to tens of  $\mu\text{m}^2$
- Feature peak-to-valley -- Å to  $\mu\text{m}$
- Sample sizes -- mm to cm
- AFM measures surfaces



# I


# AFM Schematic




# Scanners

*scanning probe microscopy*


tip scanning



sample scanning



decoupled scanning





tapping is done close to or at the cantilever  
(tapping mode will be discussed later)





# I

# AFM Instrument




# I

# AFM Schematic




# Laser Detection

non-interacting




laser spot  
(reflected from back of cantilever)

segmented photodetector



lateral direction  
(friction)




(side view)

(exaggerated schematic)

# Laser Detection


sample pushing up




(side view)

laser spot  
(reflected from back of cantilever)

segmented photodetector




lateral direction  
(friction)



(exaggerated schematic)


# Laser Detection

sample pulling down



laser spot  
(reflected from back of cantilever)

segmented photodetector




(side view)

lateral direction  
(friction)


(exaggerated schematic)

# AFM Tips


scanning *probe* microscopy



# Tip Terminology




SEM images taken using MRL's JEOL 6060LV




“probe”

tips point upwards  
in the box




# I

## Typical Tip



SEM images taken using MRL's JEOL 6060LV



common tip for imaging:

- tip radius of curvature < 10 nm
- silicon tip
- cantilever width 30  $\mu$ m
- cantilever length 125  $\mu$ m
- cantilever thickness 4  $\mu$ m



# Tip Types

- Typical tapping tip cost ~\$21
- Specialized tips cost more
  - Coatings (electrical, magnetic) usually a couple more dollars per tip
  - High aspect ratio or 2 nm radius tips ~\$70-80
  - Coaxial microwave waveguide tips ~\$150
  - Colloidal probes, coated tips, made-to-order probes available

 Non-Contact / Tapping Mode AFM Probes General dynamic mode measurements <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>	 Force Modulation (FM) AFM Probes Multi-functional probes <span style="color: orange;">★ bestsellers</span>	 Contact Mode AFM Probes General static mode measurements <span style="color: orange;">★ bestsellers</span>	 Life Science AFM Probes Biological applications <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>	 Ultra High Frequency AFM Probes High speed measurements <span style="color: orange;">★ bestsellers</span>	 Conductive AFM Probes Electrical characterization (EFM, KPFM, SSRM, TUNA, etc.) <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>
 Magnetic AFM Probes Magnetic force microscopy (MFM) <span style="color: orange;">★ bestsellers</span>	 Supersharp AFM Probes Enhanced / atomic resolution measurements <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>	 Diamond AFM Probes The ultimate in hardness <span style="color: orange;">★ bestsellers</span>	 Hardened / Enhanced Wear Resistance AFM Probes Long scanning, hard samples <span style="color: orange;">★ bestsellers</span>	 Nanoindentation and Lithography AFM Probes Nanomechanics and Sample Modification <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>	 High Aspect Ratio (HAR) AFM Probes Deep trench measurements <span style="color: orange;">★ bestsellers</span> <a href="#">» new</a>
 ScanAsyst™ AFM Probes ScanAsyst® compatible probes <span style="color: orange;">★ bestsellers</span>	 Silicon Nitride AFM Probes Soft samples in air and liquid <span style="color: orange;">★ bestsellers</span>	 Lateral Force Microscopy (LFM) AFM Probes Frictional force measurements <span style="color: orange;">★ bestsellers</span>	 Tipless AFM Cantilevers and Cantilever Arrays For functionalization and gluing spheres <span style="color: orange;">★ bestsellers</span>	 Colloidal AFM Probes Various colloidal sphere-tips for nanomechanics <span style="color: orange;">★ bestsellers</span>	 Self-Sensing & Self-Actuating AFM Probes The AFM technology of tomorrow <span style="color: orange;">★ bestsellers</span>
 Sphere AFM Tips Well defined sphere geometry for nanomechanics <a href="#">» new</a>	 Platinum Silicide AFM Probes The ultimate probes for electrical characterization <span style="color: orange;">★ bestsellers</span>	 Scanning Thermal Microscopy AFM Probes Temperature and thermal conductivity measurements <span style="color: orange;">★ bestsellers</span>	 Premounted AFM Probes For Quesant / Ambios AFM systems <span style="color: orange;">★ bestsellers</span>	 <b>NANOANDMORE USA</b> <i>The Nanotech Facilitator</i>	


# “How long does a tip last?”

- Tips are consumables
  - Contamination from samples
  - Wear from samples
  - Dropping them
- When your tip goes bad, just throw it out!
- Generally come in 10-packs
  - 50-packs for frequent AFM’ers




# The Process

- Mount tip
- Mount sample
- Scan
- Process image
- Extract numbers  
(application-dependent)




# Raster Scanning



Move probe and sample with respect to one another  
to build up an image


# I

# Feedback





# Feedback

- z piezo extension adjusted to keep feedback signal equal to setpoint
  - too much force—move away
  - too little force—move closer
  - deflection for contact mode, usually amplitude for tapping mode
- distance extended or retracted describes the height of the feature




# Contact Mode Imaging

- Drag tip along surface like a stylus profilometer (or like a record player)
- Adjust tip—sample separation to keep cantilever deflection constant
  - Traces sample topography
  - Some AFMs move tip; some move sample




# Tapping Mode Imaging


- Standard mode for AFM topography
- Intermittent contact, tapping, AC, amplitude modulation mode
- Not constantly in contact with the surface
- Driven, oscillating cantilever
- Tip—sample interactions affect oscillation



tip oscillates at tens of kHz to MHz





# Tuning the Cantilever





# Application: Imaging

Polymer  
Grating





range of colors,  
not heights in  
the image

# Reading the Colorscale




same image, different color ranges  
**color range of the displayed image,  
not necessarily all heights on the surface**



BOPP/PE polymer blend (toothbrush packaging), 10μm x 10μm AFM topograph

# I

# Interpreting 3D Images





blood cells,  $8\mu\text{m} \times 8\mu\text{m}$  AFM topograph

# I

# Interpreting 3D Images

not necessarily 1:1:1 z:x:y

z often exaggerated compared to xy to **convey texture information**




steel sample disk  
5 $\mu$ m AFM topograph

(blood and steel samples  
courtesy Physics 403 Lab 2022)



# Application: Step Heights

HOPG






# Step Heights and Thicknesses

Which book is thicker?



# Step Height: Relative Height


- Film thickness is measured by step height
- Measure a height difference
  - Leave some bare substrate (patches are OK)
  - Scratch down to the substrate
  - Multilayer material—exposed underlayer



# Step Height/Film Thickness: Complementary Techniques

If your step's too broad for the AFM  
(edge width  $>\sim 80\mu\text{m}$ ), try...

- Stylus profilometry
  - 3D optical profilometry
- } Need a height difference (step) like AFM





- X-ray Reflectivity (XRR)
  - X-ray Fluorescence (XRF)
  - Rutherford Backscattering Spectrometry (RBS)
- } Continuous film (no steps)  
May need to know density

# Width Measurements



Beware of tip shape convolution

- As depth increases, tips get broader
- Steep drop-offs look less sharp
- High aspect ratio tips are available



# Width Measurements

- As depth increases, tips get broader
- Steep drop-offs look less sharp
- High aspect ratio tips are available



# Application: Roughness


- “The roughness” depends on the scale
- Choose measurement technique to match the feature scale of interest
  - AFM (nanoscale)
  - Stylus profilometry
  - 3D optical profilometry

What is the roughness of this landscape?




Michael Jeffords and Susan Post, University of Illinois Prairie Research Institute  
<https://photojournalingm-s.smugmug.com/Colorado-and-Kansas/i-3tJ3DZk/A>

# Complementary: Stylus Profilometry



2D stylus profilometry

(line profiles)  
(diamond tip)




# Complementary: Optical Profilometry

[go.illinois.edu/MRL3DOpticalProfilometry](http://go.illinois.edu/MRL3DOpticalProfilometry)

ladybug imaged during Cena y Ciencias using the Keyence VK-X1000

image by Kathy Walsh, MRL Facilities

sample courtesy of Julio Soares, MRL Facilities




# Qualitative Comparison

	AFM	2D Stylus Profilometry	3D Optical Profilometry
Vertical resolution	outstanding	OK	OK
Field of view	small	large	large
Data type	image	line	image
Max sample size	depends on instrument (~cm to large)	large	large
Max feature height	few $\mu\text{m}$	mm	mm
Force on sample	light	moderate	none
Speed	moderate	really fast	fast

# Mechanical Characterization

## Visual impact of mechanical differences


- Phase (tapping mode)
- Force modulation, AM-FM, contact resonance, etc.
- Maps of quantitative measurement results (force mapping)



# Tapping Mode Imaging: Phase


- Oscillating cantilever
- Tip—surface interactions affect oscillation
  - Cantilever driven to keep a constant amplitude
  - Dissipative interactions cause a phase lag (delay)
    - Viscous areas
    - Sticky areas

tip oscillates really fast  
(tens of kHz to MHz)




# Phase (Qualitative)


- Tapping mode imaging
- Contrast in phase image shows differences in mechanical properties
  - Qualitative, not quantitative
  - Great for mixtures
  - Great for soft materials deposited on hard surfaces



# Topography






# Topography with Colors from Phase




# I

# Common Application: Conductive AFM




# Sample Drift

Scanning downwards...




... then scanning upwards





chewing gum

# Tip Artifacts

- Multiple tip
  - Tip contamination
  - Tip breaking
- Tip wear




# Contaminated Tip




# Tip Artifacts

- Multiple tip
  - Tip contamination
  - Tip breaking
- Tip wear




# Line-by-Line Background Subtraction

- Difference from line to line
- Tip condition changes, curvature
- Polynomial subtraction




# Image Processing

raw image



# Image Processing


line subtraction



# I

# Image Processing

line subtraction




# I

# Image Processing

line subtraction:  
mask outlier areas


areas to ignore  
when processing




# I

# Image Processing

line subtraction:  
masked flatten




# 3D Display




# 3D Display

face on




side view




raw data courtesy of Ale Baptista,  
Anton Paar Tosca 400 AFM

# 3D Display—z:xy



raw data courtesy of Ale Baptista,  
Anton Paar Tosca 400 AFM


# 3D Display—Lighting Angle



raw data courtesy of Ale Baptista,  
Anton Paar Tosca 400 AFM


# Many Other Applications

- Nanolithography/nanomanipulation
- LFM (friction, lateral force microscopy)
- EFM (electrostatic force microscopy)
- KPFM (SKPM, Kelvin probe)
- MFM (magnetic force microscopy)
- PFM (piezoresponse force microscopy)
- ... and these generally don't need extra gear  
(except different tips)



# Attachments on the MRL AFMs


- ORCA Conductive AFM
- Scanning Microwave Impedance Microscopy (sMIM)
- Environmental Controller
- BioHeater
- PolyHeater (up to 300°C)
- MFP-3D Leg Extenders
  
- blueDrive Photothermal Excitation
- Fast Force Mapping
- Dual-Gain ORCA Conductive AFM
- Piezoresponse Force Microscopy (HV-PFM)
- Contact Resonance Viscoelastic Mapping Mode
- AM-FM Viscoelastic Mapping Mode
- Scanning Tunneling Microscopy (STM)
- Air Temperature Controller (ATC)
- Droplet Cantilever Holder Kit



# MRL AFMs—B12 MRL


Asylum Research MFP-3D-SA (2 of these)

15 $\mu\text{m}$  z range, 90 $\mu\text{m}$  x 90 $\mu\text{m}$  scan size




Asylum Research Cypher

5 $\mu\text{m}$  z range, 30 $\mu\text{m}$  x 30 $\mu\text{m}$  scan size




Coming Soon: Asylum Research MFP-3D-Bio  
on an inverted optical fluorescence microscope



# Related Instruments at MRL

- Neaspec Nano-IR
  - AFM + infrared
  - Highly localized chemical information
- Molecular Vista PiFM
  - Highly localized chemical information
- Horiba TERS/TEPL
  - Tip-enhanced Raman spectroscopy
- Dektak stylus profilometer
- Keyence 3D optical profiler



Julio Soares, MRL



# Keep Learning

- MRL Webinar Series
  - [go.illinois.edu/MRLYouTubeChannel](http://go.illinois.edu/MRLYouTubeChannel)
    - Basics of Atomic Force Microscopy (Kathy Walsh)
    - The Versatility of Nanomechanics with AFM (Jessica Spear)
    - 3D Optical Profilometry (Julio Soares and Kathy Walsh)
- Kathy Walsh, [kawalsh@illinois.edu](mailto:kawalsh@illinois.edu)

