



# Wireless Media Access Protocols

# Wired Communication

## ■ Pros

- Very reliable
  - For Ethernet, medium HAS TO PROVIDE a Bit Error Rate (BER) of  $10^{-12}$  (one error for every trillion bits!)
    - Insulated wires; wires placed underground and in walls
    - Error Correction Techniques
- Very high transfer rates - currently up to 100 Gbit/s
- Long distance - Up to 40km in 10-Gbit/s Ethernet

## ■ Cons

- Expensive to set up infrastructure
- Infrastructure is fixed once set up
- No physical mobility



# Wireless Communication

## ■ Pros

- Allows mobility
- Much cheaper and easier to deploy, change, and upgrade!

## ■ Cons

- Exposed (unshielded) medium
  - Susceptible to physical phenomena (interference)
  - Variable BER – Error correction may not suffice in all cases
- Slower data rates for wider distances
- Link layer, and higher-layers, designed for wired medium
  - E.g. TCP assumes loss = congestion
  - Difficult to “hide” underlying behavior
- Security: anyone in range hears transmission



# [ Wireless ]

- FCC oversees all wireless communication
- Licensed Bands
  - Cellular phones, 3G, AM/FM radio, broadcast television, satellites, WiMax
  - Use of resources left to “owner” of band
- Unlicensed Bands
  - 802.11, Bluetooth, ZigBee, IR, WiMax
  - No license needed – free for all!
  - Restrictions to limit interference
    - Limit on transmission power
    - Spread spectrum communication

## Unlicensed Bands

900 MHz

Industrial, Scientific  
and Medical (ISM)

2.4 GHz

5.4 GHz

10 – 66 GHz




# Wireless Communication Standards (Alphabet Soup)

- Cellular (2G): GSM, CDMA, GPRS
- 3G: CDMA2000, W-CDMA, EDGE
- 4G: WiMAX, LTE
- IEEE 802.11
  - A: 5.0Ghz band, max 54Mbps
  - B: 2.4Ghz band, max 11Mbps
  - G: 2.4Ghz, max 54Mbps
  - N: 2.4/5Ghz, max 600Mbps
  - Many other versions
- IEEE 802.15 – lower power wireless
  - 802.15.1: 2.4Ghz, max 2.1 Mbps (Bluetooth)
  - 802.15.4: 2.4Ghz, max 250 Kbps (Sensor Networks)



# Wireless Link Characteristics



# [Challenges of wireless]

- Path loss
  - Signal attenuation as a function of distance
  - Signal-to-noise ratio (SNR—Signal Power/Noise Power) decreases, make signal unrecoverable
- Multipath propagation
  - Signal reflects off surfaces, effectively causing self-interference
- Internal interference (from other users)
  - Hosts within range of each other collide with one another's transmission
- External interference
  - Microwave is turned on and blocks your signal




# [ Path Loss ]

- Signal power attenuates by about  $\sim r^2$  factor for omni-directional antennas in free space
  - $r$  is the distance between the sender and the receiver
- The exponent in the factor is different depending on placement of antennas
  - Less than 2 for directional antennas
  - Faster attenuation
    - Exponent  $> 2$  when antennas are placed on the ground
    - Signal bounces off the ground and reduces the power of the signal





# Multipath Effects




- Signals bounce off surfaces and interfere with one another
- What if signals are out of phase?
  - Orthogonal signals cancel each other and nothing is received!






# [ What is a Wireless “Link”?





# [ What is a Wireless “Link”?



# Wireless Bit Errors

- The lower the SNR (Signal/Noise) the higher the Bit Error Rate (BER)
- How can we deal with this?
  - Make the signal stronger
- Why is this not always a good idea?
  - Increased signal strength requires more power
  - Increases the interference range of the sender, so you interfere with more nodes around you
- Error correction can correct **some** problems



# [ Spread Spectrum ]

- Direct Sequence Spread Spectrum
  - Spread the signal over a wider frequency band than required
  - Originally designed to thwart jamming
  - Original 802.11 uses 83 MHz in 2.4 GHz band
- Frequency-Hopped Spread Spectrum
  - Uses 80 1MHz sub-bands in 2.4 GHz band
  - Transmit over a random sequence of frequencies



# [ Spread Spectrum ]


- Direct Sequence
  - Spread the signal
  - Over the entire bandwidth
  - Over the entire frequency range
- Frequency Hopping
  - Uses a sequence of frequencies
  - Transmits a narrowband signal at each frequency
- Frequency hopping had many inventors
  - 1942: actress Hedy Lamarr and composer George Antheil patented Secret Communications System
  - Piano-roll to change between 88 frequencies, and was intended to make radio-guided torpedoes harder for enemies to detect or to jam
  - The patent was rediscovered in the 1950s during patent searches when private companies independently developed Code Division Multiple Access, a civilian form of spread-spectrum



# Direct Sequence Spread Spectrum

## ■ Spread Spectrum

- For each bit, send XOR of that bit and n random bits
- Random sequence is known to both sender and receiver
- Called n-bit chipping code (802.11 uses 11bit code)



Data stream:  
1010



Random sequence:  
0100101101011001



XOR of the two:  
1011101110101001



# Current Wireless Technologies

- IEEE 802.11
  - Wireless LAN (WLAN)
  - MAC layer based on Ethernet
    - Originally called “wireless Ethernet”

	Max Rate	Frequency	Range	Energy
Pre-802.11	2 Mbps	900 Mhz	100 m	100 mW
IEEE 802.11b	11 Mbps	2.4 GHz	35/150 m	100 mW
IEEE 802.11g	54 Mbps	2.4 GHz	35/150 m	100 mW
IEEE 802.11a	54 Mbps	5 GHz	10 /120 m	100 mW
IEEE 802.11n	600 Mbps	2.4/5 GHz	70 /250 m	100 mW





# IEEE 802.11 - Physical Layer

- IEEE 802.11 b
  - Direct Sequence Spread Spectrum
    - Uses 83 MHz in 2.4 GHz band
    - Spread the signal over a wider frequency band than required
    - Originally designed to prevent jamming
  - 3 orthogonal channels
- IEEE 802.11 g
  - Frequency-Hopped Spread Spectrum
    - Uses 80 1MHz sub-bands in 2.4 GHz band
    - Transmit over a random sequence of frequencies
      - Hop 10 times a second
    - Originally designed to avoid snooping
  - 3 orthogonal channels



# [ IEEE 802.11 - Physical Layer ]

- IEEE 802.11 a
  - Orthogonal Frequency Division Multiplexing (OFDM)
  - 13 orthogonal channels
- IEEE 802.11 n
  - Works on both 802.11a and 802.11g spectrum
  - MIMO – Multi-input, Multi-output antenna
    - Up to 4 antenna



# [ IEEE 802.11 - Physical Layer ]

- Channel Rate vs. Signal strength
  - All versions of IEEE 802.11 can reduce the rate to increase the signal strength
    - IEEE 802.11 b                      1, 2, 5.5, 11 Mbps
    - IEEE 802.11 a, g                6, 9, 12, 18, 24, 36, 48, or 54 Mbps
  - Increased range → lower signal → lower rate



# [ IEEE 802.11 Extensions ]

- IEEE 802.11e
  - Enhancements: QoS, including packet bursting
- IEEE 802.11i
  - Enhanced security
- IEEE 802.11p
  - WAVE - Wireless Access for the Vehicular Environment
- IEEE 802.11s
  - ESS Mesh Networking
- IEEE 802.11u
  - Interworking with non-802 networks (for example, cellular)
- IEEE 802.11 ac
  - Provides high throughput in the 5 GHz band
  - Wider RF bandwidth, more streams (up to 8), and high-density modulation (up to 256 QAM)



# Current Wireless Technologies

- Bluetooth – IEEE 802.15.1
  - Originally designed as a cable replacement technology
  - Master/Slave configuration
  - Piconets

	Max Rate	Frequency	Range	Energy
Bluetooth	3 Mbps	2.4 GHz	100 m	100 mW
			10 m	2.5 mW
			1 m	1 mW



# [ Bluetooth ]

- Physical Layer

- Frequency-Hopped Spread Spectrum

- Uses 79 1MHz sub-bands in 2.4 GHz band
    - Transmit over a random sequence of frequencies
      - Hop 1600 times a second
    - 5 orthogonal sub-hopping sets

- MAC Layer

- Slotted

- Managed by the master
    - Single slot packet
      - Max data rate of 172Kbps
    - Multislot frames
      - Support higher rates of 721Kbps



# Current Wireless Technologies

- ZigBee – IEEE 802.15.4
  - Low power, short range
    - Sensor networks
    - Personal area networks

	Max Rate	Frequency	Range	Energy
ZigBee (IEEE 802.15.4)	250 kbps	2.4 GHz	10 - 100 m	1 mW
	40 Kbps	915 MHz	10 - 100 m	1 mW
	20 Kbps	868 MHz	10 - 100 m	1 mW



# [ ZigBee ]

- Physical Layer
  - Direct Sequence Spread Spectrum
    - 2.4 GHz – 16 orthogonal channels
    - 915 MHz – 10 orthogonal channels
    - 868 MHz – 1 channel
- MAC Layer
  - CSMA/CA
  - Battery Life Extension (BLE) mode
    - Limit the back-off exponent to max 2





# [ Current Wireless Technologies ]

- InfraRed
  - Directional

	Max Rate	Frequency	Range	Energy
InfraRed – IrDA	9600 bps – 16 Mbps		< 1 m	Low



# Current Wireless Technologies

## ■ RFID

- Passive technology
- Used for inventory control

	Max Rate	Frequency	Range	Energy
RFID – Near Field			< 10 cm	Self-powered
RFID – Far Field			< 3 m	Self-powered



# [ RFID ]

## ■ RFID Basics

- Reader powers the “tag”
- Antenna “captures” the energy for a response
- Simple MAC
  - All tags respond
- Contention-based MAC
  - Use ALOHA or Tree-splitting algorithm to avoid collisions

## ■ Near field

- Magnetic induction
  - Range < 10 cm

## ■ Far field

- Electromagnetic wave capture
  - Range < 3 m



# Current Wireless Technologies

- WiMAX – IEEE 802.16
  - Wireless Metropolitan Area Networks (WMAN)
  - May require line-of sight (LOS)

	Max Rate	Frequency	Range	Energy
WiMAX –LOS	70 Mbps	10-66 GHz	50 km	Very high
WiMAX Non-LOS		2-11 GHz		Very high



# [ Communication Characteristics ]

- Rate
  - Defines the communication speeds
- Frequency
  - Defines the behavior in the physical environment
- Range
  - Defines the physical communication area
- Power
  - Defines the cost in terms of energy



# [ Communication Characteristics ]

## ■ Rate

- Defines the communication speeds
- Channel Bandwidth
  - Defined by the specifications of the technology
- Available Bandwidth
  - Defined by the current use of the communication channel
    - Channel competition – MAC layer
    - Bandwidth competition – Transport layer

## ■ Which is better?

- IEEE 802.11a or IEEE 802.11b



# [ Communication Characteristics ]

- Frequency/signal characteristics
  - Defines the behavior in the physical environment
    - Does the signal go through walls?
    - Is the signal susceptible to multipath fading?
  - Challenge
    - Many technologies use the same frequency
- Which is better?
  - Environment: a home with WiFi and cordless phones
  - Bluetooth or 802.11?



# [ Communication Characteristics ]

## ■ Range

- Defines the physical communication area
- May be affected by buildings, walls, people
- May be affected by distance

## ■ Which is better?

- InfraRed or ZigBee?





# [ Communication Characteristics ]

- Power

- Defines the cost in terms of energy
- Power can be adapted to save energy
  - Inversely affects range

- Which is better?



- IEEE 802.11g or ZigBee?



# Medium Access Control

- IEEE 802.11

- A physical and multiple access layer standard for wireless local area networks (WLAN)




# [ Medium Access Control ]

- Wireless channel is a shared medium
- Need access control mechanism to avoid interference
- Why not CSMA/CD?




# Ethernet MAC Algorithm



- Listen for carrier sense before transmitting
- Collision: What you hear is not what you sent!

# [ CSMA/CD in WLANs? ]

- Most (if not all) radios are half-duplex
  - Listening while transmitting is not possible
- Collision might not occur at sender
  - Collision at receiver might not be detected by sender!




# [ Wireless Ethernet - CSMA/CA ]

- CS – Carrier Sense
  - Nodes can distinguish between an idle and a busy link
- MA - Multiple Access
  - A set of nodes send and receive frames over a shared link
- CA – Collision **Avoidance**
  - Nodes use protocol to prevent collisions from occurring




# IEEE 802.11 MAC Layer Standard

- Similar to Ethernet
- But consider the following:



# [ Hidden Terminal Problem ]


- Node B can communicate with both A and C
- A and C cannot hear each other
- When A transmits to B, C cannot detect the transmission using the carrier sense mechanism
- If C transmits, collision will occur at node B






# MACA Solution for Hidden Terminal Problem

- When node A wants to send a packet to node B
  - Node A first sends a Request-to-Send (RTS) to B
- On receiving RTS
  - Node B responds by sending Clear-to-Send (CTS)
  - provided node B is able to receive the packet
- When a node C overhears a CTS, it keeps quiet for the duration of the transfer




# IEEE 802.11 MAC Layer Standard

- But we still have a problem




# Exposed Terminal Problem

- B talks to A
- C wants to talk to D
- C senses channel and finds it to be busy
- C stays quiet (when it could have ideally transmitted)



# MACA Solution for Exposed Terminal Problem

- Sender transmits Request to Send (RTS)
- Receiver replies with Clear to Send (CTS)
- Neighbors
  - See CTS - Stay quiet
  - See RTS, but no CTS - OK to transmit



# IEEE 802.11 MAC Layer Standard

- MACAW – Multiple Access with Collision Avoidance for Wireless
  - Sender transmits Request to Send (RTS)
  - Receiver replies with Clear to Send (CTS)
  - Neighbors
    - See CTS
      - Stay quiet
    - See RTS, but no CTS
      - OK to transmit
  - Receiver sends ACK for frame
    - Neighbors stay silent until they hear ACK



# [ Collisions ]

- Still possible
  - RTS packets can collide!
- Binary exponential backoff
  - Backoff counter doubles after every collision and reset to minimum value after successful transmission
  - Performed by stations that experience RTS collisions
- RTS collisions not as bad as data collisions in CSMA
  - Since RTS packets are typically much smaller than DATA packets




# [ Reliability ]

- Wireless links are prone to errors
  - High packet loss rate detrimental to transport-layer performance
- Mechanisms needed to reduce packet loss rate experienced by upper layers



# A Simple Solution to Improve Reliability - MACAW


- When node B receives a data packet from node A, node B sends an Acknowledgement (ACK)
- If node A fails to receive an ACK
  - Retransmit the packet





# Revisiting the Exposed Terminal Problem

- Problem
  - Exposed terminal solution doesn't consider CTS at node C
- With RTS-CTS, C doesn't wait since it doesn't hear A's CTS
  - With B transmitting DATA, C can't hear intended receiver's CTS
  - C trying RTS while B is transmitting is useless




# Revisiting the Exposed Terminal Problem - MACAW

- One solution
  - Have C use carrier sense before RTS
- Alternative
  - B sends DS (data sending) packet before DATA
    - Short packet lets C know that B received A's CTS
    - Includes length of B's DATA so C knows how long to wait




# [Deafness]

- For the scenario below
  - Node A sends an RTS to B
    - While node C is receiving from D,
  - Node B cannot reply with a CTS
    - B knows that D is sending to C
    - A keeps retransmitting RTS and increasing its own BO timeout




# Request for RTS - MACAW

- Have B do contention on behalf of A
  - If B receives RTS for which it must defer CTS reply
  - Then B later sends RRTS to A when it can send
  - A responds by starting normal RTS-CTS
  - Others hearing RRTS defer long enough for RTS-CTS



# Another MACAW Proposal

- This approach, however, does not work in the scenario below
  - Node B may not receive the RTS from A at all, due to interference with transmission from C



# [ Broadcast/Multicast ]

## ■ Problem

- Basic RTS-CTS only works for unicast transmissions

## ■ For multicast

- RTS would get CTS from each intended receiver
- Likely to cause (many) collisions back at sender



# [ Multicast - MACAW ]

- Sort-of solution
  - Don't use CTS for multicast data
- Receivers recognize multicast destination in RTS
  - Don't return CTS
  - Sender follows RTS immediately by DATA
  - After RTS, all receivers defer for long enough for DATA
- Helps, but doesn't fully solve problem
  - Like normal CSMA, only those in range of sender will defer
  - Others in range of receiver will not defer



# IEEE 802.11 Wireless MAC


- Distributed and centralized MAC components
  - Distributed Coordination Function (DCF)
  - Point Coordination Function (PCF)
- DCF suitable for multi-hop ad hoc networking
- DCF is a Carrier Sense Multiple Access/Collision Avoidance (CSMA/CA) protocol





# IEEE 802.11 DCF

- Uses RTS-CTS exchange to avoid hidden terminal problem
  - Any node overhearing a CTS cannot transmit for the duration of the transfer
- Uses ACK to achieve reliability
- Any node receiving the RTS cannot transmit for the duration of the transfer
  - To prevent collision with ACK when it arrives at the sender
  - When B is sending data to C, node A keeps quite




# [ IEEE 802.11 CSMA/CA ]

- Nodes stay silent when carrier sensed
  - Physical carrier sense
  - Virtual carrier sense
    - Network Allocation Vector (NAV)
    - NAV is updated based on overheard RTS/CTS/DATA/ACK packets, each of which specified duration of a pending transmission
- Backoff intervals used to reduce collision probability






# IEEE 802.11 Physical Carrier Sense




# IEEE 802.11 Virtual Carrier Sense




# IEEE 802.11 Virtual Carrier Sense

**NAV** = remaining duration to keep quiet


RTS = Request-to-Send



# IEEE 802.11 Virtual Carrier Sense




# IEEE 802.11 Virtual Carrier Sense



# IEEE 802.11 Virtual Carrier Sense


- DATA packet follows CTS






# IEEE 802.11 Virtual Carrier Sense

- Successful data reception acknowledged using ACK




# [ IEEE 802.11 ]




# [ Interframe Spacing ]

- Interframe spacing
  - Plays a large role in coordinating access to the transmission medium
- Varying interframe spacings
  - Creates different priority levels for different types of traffic!
- 802.11 uses 4 different interframe spacings



# IEEE 802.11 - CSMA/CA

- Sensing the medium
- If free for an Inter-Frame Space (IFS)
  - Station can start sending (IFS depends on service type)
- If busy
  - Station waits for a free IFS, then waits a random back-off time (collision avoidance, multiple of slot-time)
- If another station transmits during back-off time
  - The back-off timer stops (fairness)



# [Types of IFS]

## ■ SIFS

- Short interframe space
- Used for highest priority transmissions
- RTS/CTS frames and ACKs

## ■ DIFS

- DCF interframe space
- Minimum idle time for contention-based services ( $>$  SIFS)



# [Types of IFS]

## ■ PIFS


- PCF interframe space
- Minimum idle time for contention-free service ( $>$ SIFS,  $<$ DIFS)

## ■ EIFS

- Extended interframe space
- Used when there is an error in transmission



# IEEE 802.11 - Competing Stations



busy

medium not idle (frame, ack etc.)

bo<sub>e</sub>

elapsed backoff time



packet arrival at MAC

bo<sub>r</sub>

residual backoff time




# [ Backoff Interval ]

- When transmitting a packet, choose a backoff interval in the range  $[0, CW]$ 
  - CW is contention window
- Count down the backoff interval when medium is idle
  - Count-down is suspended if medium becomes busy
- When backoff interval reaches 0, transmit RTS





# [ DCF Example ]



CW = 31

B1 and B2 are backoff intervals  
at nodes 1 and 2



# [ Backoff Interval ]

- The time spent counting down backoff intervals is a part of MAC overhead
- Large CW
  - Large backoff intervals
  - Can result in larger overhead
- Small CW
  - Larger number of collisions (when two nodes count down to 0 simultaneously)



# [ Backoff Interval ]

- The number of nodes attempting to transmit simultaneously may change with time
  - Some mechanism to manage contention is needed
- IEEE 802.11 DCF
  - Contention window CW is chosen dynamically depending on collision occurrence




# Binary Exponential Backoff in DCF

- When a node fails to receive CTS in response to its RTS, it increases the contention window
  - cw is doubled (up to an upper bound)
- When a node successfully completes a data transfer, it restores cw to  $CW_{\min}$ 
  - cw follows a sawtooth curve




# [ Fairness Issue ]

- Many definitions of fairness plausible
- Simplest definition
  - All nodes should receive equal bandwidth



# Fairness Issue

- Assume that initially, A and B both choose a backoff interval in range  $[0,31]$  but their RTSs collide
- Nodes A and B then choose from range  $[0,63]$ 
  - Node A chooses 4 slots and B chooses 60 slots
  - After A transmits a packet, it next chooses from range  $[0,31]$
  - It is possible that A may transmit several packets before B transmits its first packet



**Two flows**




# [ Fairness Issue ]

- Unfairness occurs when one node has backed off much more than some other node
- MACAW Solution
  - When a node transmits a packet
    - Append the cw value to the packet
    - all nodes hearing that CW value use it for their future transmission attempts




# Channelization of spectrum

- Typically, available frequency spectrum is split into multiple channels
- Some channels may overlap





# Preventing Collisions Altogether



- Frequency Spectrum partitioned into several channels
  - Nodes within interference range can use separate channels
  - Now A can send to B while C sends to D without any interference!
  - Aggregate Network throughput doubles

# [ Using Multiple Channels ]

- 802.11: AP's on different channels
  - Usually manually configured by administrator
  - Automatic Configuration may cause problems
- Most cards have only 1 transceiver
  - Not Full Duplex: Cannot send and receive at the same time
- Multichannel MAC Protocols
  - Automatically have nodes negotiate channels
    - Channel coordination amongst nodes is necessary
    - Introduces negotiation and channel-switching latency that reduce throughput




# Wireless Multihop Networks

- Vehicular Networks
  - Delay Tolerant (batch) sending over several hops carry data to a base station
- Common in Sensor Network for periodically transmitting data
  - Infrastructure Monitoring
    - E.g., structural health monitoring of the Golden Gate Bridge
- Multihop networking for Internet connection sharing
  - Routing traffic over several hops to base station connected to Internet




# Multi-Hop Wireless Networks

- In an ideal world ...




# Multi-Hop Wireless Networks

- In an ideal world ...



# Multi-Hop Wireless Networks

## Reality check ...




### Problem 1

- Node A can't use both links at the same time

# Multi-Hop Wireless Networks

## Reality check




# Multi-Hop Wireless Networks

## Reality check ...

RTS/CTS helps with contention but wastes resources

1
2
3
4
5
6
7
8
9
10
11
12



### Problem 3

- Lots of contention for the channels
- Everyone wants to send




# Multi-Hop Wireless Networks

## Reality check ...

RTS/CTS helps with contention but wastes resources

1
2
3
4
5
6
7
8
9
10
11
12



### Problem 4

- TCP uses ACKS and bidirectional channels
- Even more contention!